

CLASSIC JOYPAD CONVERTER for(FC)



Slow Motion:

If hold down *FunctionA* button and then press *SELECT* button, the Slow motion function will enable,
If hold down *FunctionA* button and then press *START* button, the Slow motion function will disable.

Level 2 Turbo Fire on button A:

Hold down *Function B* button and press *turbo A* button.

Level 2 Turbo Fire on button B:

Hold down *Function B* button and press *turbo B* button.