

CLASSIC JOYPAD CONVERTER for(GENESIS)



Slow Motion:

If hold down *FunctionB* button and then press *MODE* button, the Slow motion function will enable,
If hold down *FunctionA* button and then press *MODE* button, the Slow motion function will disable.

Level 1 Turbo Fire:

Hold down *Function A* button and press *A, B* or *C* button.

Level 2 Turbo Fire:

Hold down *Function B* button and press *A, B* or *C* button.