

CLASSIC JOYPAD CONVERTER for(NEO-GEO)



Slow Motion:

If hold down *FunctionB* button and then press SELECT button, the Slow motion function will enable,
If hold down *FunctionA* button and then press SELECT button, the Slow motion function will disable.

Level 1 Turbo Fire:

Hold down *Turbo B* button and press PAD A, B, C or D button.

Level 2 Turbo Fire:

Hold down *Turbo A* button and press PAD A, B, C or D button.