

CLASSIC JOYPAD CONVERTER for(SATURN)



Slow Motion:

If hold down *L* button and then press *MODE* button, the Slow motion function will enable,
If hold down *Y* button and then press *MODE* button, the Slow motion function will disable.

Turn on Turbo Fire button function :

Hold down *MODE* button and press *R* + *A, B, C, X, Y* or *Z* button.

Turn off Turbo Fire button function:

Hold down *MODE* button and press *A, B, C, X, Y* or *Z* button.